




VENTILATING FAN

مروحة تهوية

كتيب التعليمات Instruction Manual

E-20F / E-25F / E-30F / E-35F / E-40F / E-45F / E-50F





This instruction manual is designed to enable you to understand products in right way. Please keep it for your reference. The instructions shall state the substance of the followings:

This appliance is not intended for use by person (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.

هذا الجهاز غير معد للاستعمال من قبل الاشخاص (بما في ذلك الاطفال) ذوي الاعاقة الجسدية او الحسية او العقلية او الاشخاص الذين ليس عندهم خبرة او معرفة بمثل هذه الاجهزة الا اذا تم الاشراف عليهم واعطائهم التعليمات التي تتعلق باستعمال الجهاز من قبل شخص مسؤول عن سلامتهم .
يجب مراقبة والأشراف على الاطفال لضمان عدم عبثهم بالجهاز.

Technical data & Dimension

بيانات تقنية & الأبعاد



GRILL

BODY

FAN

BRACKET

MOTOR

Dimension

الأبعاد

Model	A	B	C	D	E (ø)
E-20F	300	275	120	158	200
E-25F	350	325	140	158	250
E-30F	400	375	160	165	300
E-35F	445	415	200	165	350
E-40F	500	450	240	200	400
E-45F	620	560	278	245	450
E-50F	620	560	278	245	500

(Unit : mm)

Technical data

بيانات تقنية

Model	Fan size (mm)	Power (W)	Frequency (Hz)	Class	Pole (P)	Input (W)	Current (A)	R.P.M	Air volume (m³/h)	Power factor(%)	Weight (Kg)
E-20F	200	220	60	"B"	4	50	0.22	1,680	1,060	99	2.7
E-25F	250					56	0.25	1,600	1,780	99	3.6
E-30F	300					73	0.32	1,640	2,400	99	4.0
E-35F	350					98	0.44	1,560	3,400	99	5.0
E-40F	400					150	0.69	1,600	4,810	97	7.2
E-45F	450					280	1.38	1,720	9,850	95	14.1
E-50F	500					400	1.82	1,650	11,700	99	15.2

Installation


التركيب

Installation on Wall

التركيب على الجدار


1. Make a rectangular hole on wall and fix four pieces of bolts.
1. اعمل فتحة مستطيلة على الجدار وثبت اربع براغي في الجوانب.

2. Fix the fan body with bolts, nuts, and washers.
2. ثبت جسم المروحة بالبراغي والصمولات والمسامير.



Model	A	B
E-20F	210	275
E-25F	260	325
E-30F	310	376
E-35F	360	415
E-40F	410	450
E-45F	460	560
E-50F	510	560

(Unit : mm)



Customer Service

خدمة الزبائن

For more details and technical support, contact official HESHAM ELSEWEDY TRADING CO.LTD. or Customer Service Center

لمزيد من التفاصيل والدعم الفني اتصل بوكيل شركة HESHAM ELSEWEDY TRADING CO.LTD. او مركز خدمة الزبائن



HESHAM ELSEWEDY TRADING CO. LTD.

OMAR HESHAM EL-SEWEDY BUILDING, BALADIA ST. AZIZIA DIST., JEDDAH, SAUDI ARABIA
TEL: +966 12 6644350 FAX: +966 12 6635133